



## **Trimax® Structural Lumber Installation Instructions**

Carefree Xteriors® Trimax® Structural Lumber can be fabricated and installed with the same tools used for wood lumber. Because it has no grain or knots, it can be drilled and cut cleanly. Trimax® is reinforced with fiberglass, so precautions should be taken when fabricating this product. Maintain adequate ventilation and use a dust mask and protective eyewear.

This summary is to provide the Carefree Xteriors® Decking Systems installer with basic instructions for properly installing Carefree Xteriors® residential decking systems. However, the installer and/or purchaser of any Carefree Xteriors® product is solely responsible for interpreting specific job conditions, determining the suitability of use or application of any Carefree Xteriors® product, or whether structures meet requirements of applicable building codes or safety codes for specific damages of any kind whatsoever from the provisions of the information. Minor color variations and normal wear and tear are not warranted. Variations in color are inherent in the recycled nature of the products.